

model			Shaft diameter (mm)	Installation method
Light preload	Medium preload	Heavy preload		
GBK10-SL□	GBK10-SM□	GBK10-SH□	10	BK
GBK12-SL□	GBK12-SM□	GBK12-SH□	12	BK
GBK15-SL□	GBK15-SM□	GBK15-SH□	15	BK
GBK17-SL□	GBK17-SM□	GBK17-SH□	17	BK
GBK20-SL□	GBK20-SM□	GBK20-SH□	20	BK
GBK25-SL□	GBK25-SM□	GBK25-SH□	25	BK
GBK30-SL□	GBK30-SM□	GBK30-SH□	30	BK
GBK35-SL□	GBK35-SM□	GBK35-SH□	35	BK
GBK40-SL□	GBK40-SM□	GBK40-SH□	40	BK